

Efficient ADC Testing Condition with Histogram Method

Yujie Zhao, Anna Kuwana, Shuhei Yamamoto, Yuto Sasaki,
Haruo Kobayashi, Takayuki Nakatani, Kazumi Hatayama

Keno Sato, Takashi Ishida,

Toshiyuki Okamoto, Tamotsu Ichikawa

Division of Electronics and Informatics

Gunma University

ROHM Semiconductor



Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Metallic Ratio and Prime Number Ratio
- Conclusion


Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Metallic Ratio and Prime Number Ratio
- Conclusion

Background


IoT (Internet of Things)

The application of digital signal and analog signal conversion is very extensive.



◆ Analog signal
(sound, light)

◆ Digital signal
(Binary number)



Research Objective & Approach

Analog-to-Digital Converter (ADC) Linearity Test

Test cost is proportional to test time

the low-sampling-rate high-resolution ADC


- low-speed sampling
- high-resolution

take a long time



This Work

Increasing
the sampling efficiency




Propose “short-time”
Relationship Between
Input Frequency and
Sampling Frequency

Outline

- Objective
- **ADC Test with Histogram Method**
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Metallic Ratio and Prime Number Ratio
- Conclusion

Conventional Linearity Testing 1

■ Histogram method (Ramp wave input)




DNL
INL

- ADC output histograms for all bins are equal if ADC is perfectly linear
- Highly linear ramp signal generation is difficult



Conventional Linearity Testing 2


■ Histogram method (Single sine wave input)



- The number of samples is small around the middle of output codes
- High accuracy sine wave can be generated using an analog filter



DNL & INL



- Important testing for ADCs

DNL : Difference between an actual step width and the ideal value


INL : Deviation from ideal conversion line

$$INL(k) = \sum_{i=1}^k DNL(i)$$

Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Metallic Ratio and Prime Number Ratio
- Conclusion

Sine Wave Histogram



Repetitive waveform sampled with asynchronous




Compose a 1-period waveform


The sampled histogram is compared with the PDF. The histogram is measured, DNL and INL are calculated.

Probability Distribution Function

$$p(v) = \frac{1}{\pi\sqrt{A^2 - v^2}}$$




Waveform Missing




A large amount of data is required to reproduce the waveform → Test time: long


Waveform Missing





Waveform Missing



Normal situation






Waveform Missing



Golden Ratio

Golden Ratio : $\lim_{n \rightarrow \infty} \frac{F_n}{F_{n-1}} = 1.618033988749895 = \varphi$

The most beautiful ratio





Golden Ratio

Golden ratio φ

$$f_{CLK} = \varphi \times f_{sig}$$

$$\varphi = 1.6180339887\dots$$



Outline



- Objective
- ADC Test with Histogram Method
- **Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method**
 - Sine Wave Histogram and Waveform Missing
 - **Metallic Ratio and Prime Number Ratio**
- Conclusion

Metallic ratio

Golden Ratio : $\lim_{n \rightarrow \infty} \frac{F_n}{F_{n-1}} = 1.618033988749895 = \varphi$

n		Decimal	
0	1		
1	$\frac{1 + \sqrt{5}}{2}$	1.6180339887...	Golden ratio φ
2	$1 + \sqrt{2}$	2.4142135623...	Silver ratio
3	$\frac{3 + \sqrt{13}}{2}$	3.3027756377...	Bronze ratio
4	$2 + \sqrt{5}$	4.2360679774...	
...		...	
n		$\frac{n + \sqrt{n^2 + 4}}{2}$	


Histogram of Saw wave



Total number of samples is M and
ADC resolution (the number of the histogram) is N .

$$\text{ideal value } h_i(k) = \frac{M}{N}, k = 1, 2, 3, \dots, N \quad \text{error } e(k) = \frac{N \cdot h(k)}{M} - 1$$

ADC Resolution 3Bit N = 8, Increase M




Root-Mean-Square of the errors between
the actual and ideal histograms




$$RMS = \sqrt{\frac{\sum(e(k))^2}{N}}$$

RMS between the actual and ideal




Total number of samples $M = 2048$, Increase resolution N . Compare RATIO

RMS of Prime Number Ratio



Total number of samples $M = 2048$, Increase resolution N . Compare RATIO
 Most of the RMS results are not as good as Metallic ratio.

RMS results within a range(1~4)



Therefore, we calculated the RMS within a certain range (1~4) to find a good ratio.

Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram
 - Random Sampling and Waveform Missing
 - Metallic Ratio and Prime Number Ratio
- Conclusion

Conclusion

Golden ratio sampling
Efficiency: Highest
Sampling frequency: low



Metallic ratio sampling
Efficiency: Good
Sampling frequency: High

Prime number ratio sampling
Efficiency: Not Good
Sampling frequency: High

next issue

- Find a ratio that is more efficient and has a smaller RMS like the golden ratio