

Input Signal and Sampling Frequencies Requirements for Efficient ADC Testing with Histogram Method

Yujie Zhao, A. Kuwana, S. Yamamoto, Y. Sasaki

H. Kobayashi, S. Katayama, J. Wei

T. Nakatani, K. Hatayama

K. Sato, T. Ishida,

T. Okamoto, T. Ichikawa

Division of Electronics and Informatics

Gunma University

ROHM Semiconductor



Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequencies Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - Metallic Ratio Sampling
 - Prime Number Ratio Sampling
- Conclusion



Outline


- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - Metallic Ratio Sampling
 - Prime Number Ratio Sampling
- Conclusion



Background

IoT era is coming !

ADC is a key component



High quality & Low cost ADC test is required



Research Objective & Approach

SAR ADC linearity test takes a long time

- low-speed sampling
- high-resolution



Test cost is proportional to test time

This Work

ADC linearity test with histogram method:
Investigation of “high efficiency relationship”
between input and sampling frequencies




Outline

- Objective
- **ADC Test with Histogram Method**
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - Metallic Ratio Sampling
 - Prime Number Ratio Sampling
- Conclusion



Conventional Linearity Testing 1

■ Histogram method (Ramp wave input)




- ADC output histograms for all bins are equal if ADC is perfectly linear
- Highly linear ramp signal generation is difficult (limitation up to 14-bit ADC)



Conventional Linearity Testing 2


■ Histogram method (Single sine wave input)



- Low distortion sine using an analog filter
- Number of samples is small around the middle of output range → Many samples required (long test time)



DNL & INL



- Important ADC testing items

DNL : Difference between actual step width and ideal value

INL : Deviation from ideal conversion line

$$INL(k) = \sum_{i=1}^k DNL(i)$$




Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequencies Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - Metallic Ratio Sampling
 - Prime Number Ratio Sampling
- Conclusion



Sine Wave Histogram



Repetitive waveform sampled asynchronously




Reconstruct a 1-period waveform

- Sampled histogram is compared with **PDF**.
- Histogram is obtained. - DNL , INL are calculated.

PDF:
Probability Distribution Function

$$p(v) = \frac{1}{\pi\sqrt{A^2 - v^2}}$$




Waveform Missing

Repetitive waveform sampled asynchronously




Reconstruct a 1-period waveform




A large amount of data is required to reconstruct the waveform → Test time: long




Waveform Missing





Waveform Missing for Saw Signal



Normal situation



Waveform Missing



Outline




- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - **Golden Ratio Sampling**
 - Metallic Ratio Sampling
 - Prime Number Ratio Sampling
- Conclusion



Golden Ratio

Golden Ratio: $\lim_{n \rightarrow \infty} \frac{F_n}{F_{n-1}} = 1.618033988749895 = \varphi$

The most beautiful ratio




Golden Ratio Sampling

Golden Ratio φ

$$f_{CLK} = \varphi \times f_{sig}$$

$$\varphi = 1.6180339887\dots$$



Proposal of sampling conditions for the highest waveform acquisition efficiency



Yuto Sasaki, Yujie Zhao, Anna Kuwana and Haruo Kobayashi, "Highly Efficient Waveform Acquisition Condition in Equivalent-Time Sampling System", 27th IEEE Asian Test Symposium, Hefei, Anhui, China (Oct. 2018)



Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - **Metallic Ratio Sampling**
 - Prime Number Ratio Sampling
- Conclusion



Metallic Ratio


Golden Ratio: $\lim_{n \rightarrow \infty} \frac{F_n}{F_{n-1}} = 1.61803398874989\dots = \varphi$

n		Decimal	
0	1		
1	$\frac{1 + \sqrt{5}}{2}$	1.6180339887...	Golden Ratio
2	$1 + \sqrt{2}$	2.4142135623...	Silver Ratio
3	$\frac{3 + \sqrt{13}}{2}$	3.3027756377...	Bronze Ratio
4	$2 + \sqrt{5}$	4.2360679774...	
...		...	
n		$\frac{n + \sqrt{n^2 + 4}}{2}$	


Generalization of Golden Ratio



Histogram of Saw Signal



Number of
Samples




Total number of samples: M

ADC resolution : N .

$$\text{ideal value } h_i(k) = \frac{M}{N}, k = 1, 2, 3, \dots, N \quad \text{error } e(k) = \frac{N \cdot h(k)}{M} - 1$$


RMS Error Calculation

Total number of samples: M=65536



Root mean square error
between actual and ideal histograms



$$RMS = \sqrt{\frac{\sum(e(k))^2}{N}}$$


Outline


- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - Metallic Ratio Sampling
 - **Prime Number Ratio Sampling**
- Conclusion



RMS of Prime Number Sampling

$$f_{CLK} = f_{sig} \times \text{RATIO} \downarrow$$

Total number of samples: M=65536




RATIO with two large prime numbers \Rightarrow Small RMS
 In contrast, Golden Ratio has a smaller RMS



RMS of Prime Number Sampling: **Big Number Case**

Total number of samples: M=65536




f_{CLK} : Big prime number 997 N
 f_{SIG} : Some prime numbers 389,599,751,853,907,953,991
 → almost the same



RMS Comparison

Total number of samples: $M=65536$



Increasing N to 16384,
Bronze ratio result is better (RMS range is smaller)



Outline

- Objective
- ADC Test with Histogram Method
- Input Sine Wave and Sampling Frequency Relationship in ADC Histogram Test Method
 - Sine Wave Histogram and Waveform Missing
 - Golden Ratio Sampling
 - Metallic Ratio Sampling
 - Prime Number Ratio Sampling
- Conclusion



Conclusion

Golden Ratio sampling

Efficiency: **high**

Sampling frequency: **low**



Metallic ratio sampling

Efficiency: **high**

Sampling frequency: **high**

Prime number ratio sampling

Efficiency: **Not good**

Sampling frequency: **low**

Next work

- Like the golden ratio

Find conditions for efficient sampling
at a specific location

(ADC resolution $N=256, 512, 1024, 2048, 4096$)



Thanks for your attention.

